



# Base plate **BS-20**

Provides the opportunity to build up the laser or another measurement device directly above the ground or a pillar.



**BS-20 with  
Quick Fix Nedo**  
Order-No. 0056.00.2



**BS-20 with  
Standard tripod adapter**  
Order-No. 0056.00.1



**BS-20 with Plumb Laser**